

1

Copper foil tape
30mm
10mm

2

Boot
Cable

3

30mm Min.
10mm
or
30mm Min.
10mm
S/FTP
U/FTP.F/UTP

4

30mm Min.
10mm
Copper foil tape

5

7/8 4/5 3/6 1/2
7/8 4/5 3/6 1/2
7/8 4/5 3/6 1/2
7/8 4/5 3/6 1/2

6

7

5~8mm Max.

8

Cut 2
Cut 1
0.2mm Max.

9

Align

10 Hand screwing

1 Close
2 Push
3 Screw

11

NG
OK

12

	Solid	Stranded	Cable (O.D.)
C6 _A /C7	23~26AWG	23~26AWG	6.0~7.5mm
C8	22~24AWG	22~24AWG	7.0~8.5mm

1

Cinta de lámina de cobre
30mm
10mm

2

Bota
Cable

3

30mm Min.
10mm
S/FTP
U/FTP.F/UTP

4

30mm Min.
10mm
Cinta de lámina de cobre

5

7/8 4/5 3/6 1/2
4/5 7/8 3/6 1/2
7/8 4/5 3/6 1/2
7/8 4/5 3/6 1/2

6

7

5~8mm Máx.

8

Corte 2 -
Corte 1 -
0,2mm Máx.

9

Alinear

10 Atornillar manualmente

1 Cerrar
2 Presionar
3 Atornillar

11

Incorrecto
Correcto

12

	Sólido	Trenzado	Cable (D.E.)
C6 _A /C7	23~26AWG	23~26AWG	6,0~7,5mm
C8	22~24AWG	22~24AWG	7,0~8,5mm