



Smart **Wi-Fi LED**
color bulb

User guide

Thank you for purchasing the **Smart Wi-Fi LED bulb** from Nexxt Solutions. We are excited to be part of making your life easier, safer and bringing peace of mind into your homes.

Product overview


1. LED: Displays various lighting colors according to your preferred settings through the application
2. Twist and lock GU10 base



Package content


- Smart LED RGB bulb
- Quick start guide

Installing the Nexxt Solutions Home App



Download Nexxt Home app from Google Play or Apple App Store.


Step 1



A smartphone screen displaying a registration form. The status bar at the top shows signal strength, Wi-Fi, the time 9:41 AM, and 50% battery. The app interface has a back arrow in the top left. The main heading is 'Register by email'. Below it is a dropdown menu showing 'United States of America' with a chevron icon. Underneath is an 'Email' input field. At the bottom is a grey button labeled 'Get authentication code'.

Register by email. Fill in the required fields.


Step 2



A smartphone screen displaying a verification code entry form. The status bar at the top shows signal strength, Wi-Fi, the time 9:41 AM, and 50% battery. The app interface has a back arrow in the top left. The main heading is 'Enter verification code'. Below it are five horizontal lines for entering digits, with the first line highlighted in orange. At the bottom, text reads 'Verification code has been sent to your'.


Enter the verification code you received.

Step 3




Create a new password and then select **Completed**.

Step 4



The Nexxt Solutions Home App account has been successfully set up.


Bulb installation



Twist the LED color bulb clockwise into the GU10 socket until it locks in place.


Add device

Step 1




Select **Add device**, followed by the smart bulb.

Step 2




Power on the smart bulb. You must connect to a **2.4GHz Wi-Fi network**. Enter your network password. Make sure you enter the correct password, otherwise the device will not connect.

Step 3




Make sure the bulb is blinking. If it fails to blink, reset the bulb. Turn it off from the switch, wait 5 seconds before turning it back on again. Tap on **Confirm the light blinks rapidly**.

Step 4



When **Device added successfully** is displayed, assign a location and click on **Done**.

Functions



Bulb: Turns the bulb on and off.

White: Changes the brightness and white color temperature.


Color: Changes the color, brightness, and saturation of the bulb.

Scene: Gives you several preselected scenes and four scenes you can configure.

Schedule: Allows you to add time and day schedule for the device to turn on or off.


Schedule setup

Step 1




Click on the **schedule** icon to access the **Add schedule** screen.

Step 2



Set the time you wish to schedule. Select **Repeat** to set settings. Select **Switch** to schedule on/off status. Select **Note, Notification** to enable or disable notifications. Click on **Save** on the upper right-hand corner to save a schedule.


Delete setup



To remove a schedule on iOS, slide item to the left, and for Android, press and hold **Schedule**, followed by **Delete**.

Settings

Click on the pencil icon on the upper right-hand corner.



Device name: changes the icon and the name of the device, and it also allows the user to assign a different location.

Note: click on the pencil icon to access the device name menu.

Device information: displays detailed information related to the bulb.

Tap-To-Run and Automation: links the Wi-Fi bulb with other smart products to automatically control them through a customized command.

Third-party control: enables the voice recognition feature through Alexa and Google Assistant.

Offline notification: provides a selection button to enable/ disable this feature.

Share device: allows sharing the Wi-Fi bulb with family and friends.

Create group: makes management of devices easier by selecting and arranging multiple components under a single group.


Feedback: let us know if you have any issues setting up the product.

Add home screen: adds a shortcut of the device to the main screen on your phone.

Check for firmware update: we will sometimes add new features or provide updates with a new firmware upgrade.

Remove device: allows you to unbind the device from the Nexxt Home Account


Share device



Click on **Share devices** then tap **Add sharing**. Enter the mobile number/e-mail address of family and friends. Tap on **Done**. The newly configured users will now have access to your smart bulb.

Note: family or friends will need their own Nexxt Solutions Home Account to access the device.

Delete user



To remove a user, on Android press and hold the name you want to eliminate. On iOS slide to the left the user you want to remove. Click on **Delete**. A notification confirming you don't want to share the device with this user will be displayed. Click on **Confirm**.



FCC ID: X4YHABUC310 / X4YHABUC320

Nexxt Solutions® is a registered trademark. All rights reserved. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates. Google, Android and Google Play are trademarks of Google Inc. All other brand names and trademarks are the property of their respective owners. Made in China.

Guía del usuario

Gracias por adquirir la **Bombilla inteligente Wi-Fi con LED** de Nexxt Solutions. Nos complace ser parte de la solución destinada no sólo a simplificar su vida, sino que además poder brindar más seguridad y tranquilidad al interior de su hogar.

Descripción del producto


1. LED: Exhibe los diversos colores de iluminación conforme a los parámetros seleccionados a través de la aplicación.
2. Base de acoplamiento a presión GU10



Contenido del empaque


- Bombilla LED inteligente con RGB
- Guía de configuración rápida

Instalación de la aplicación Nexxt Solutions Home



Descargue la aplicación Nexxt Solutions Home de Google Play o Apple App Store.


Paso 1



Smartphone screen showing the 'Register by email' form. The status bar at the top displays signal strength, Wi-Fi, 9:41 AM, and 50% battery. The screen has a back arrow in the top left. The main heading is 'Register by email'. Below it is a dropdown menu for 'United States of America' with a right arrow. There is an 'Email' input field. At the bottom is a grey button labeled 'Get authentication code'.

Registro por email. Complete los campos requeridos.


Paso 2



Smartphone screen showing the 'Enter verification code' screen. The status bar at the top displays signal strength, Wi-Fi, 9:41 AM, and 50% battery. The screen has a back arrow in the top left. The main heading is 'Enter verification code'. Below it is a horizontal line with five dashes, where the first dash is orange. At the bottom, it says 'Verification code has been sent to your'.

Ingresa el código de verificación que recibió.

Paso 3




Cree una contraseña nueva y seleccione **Completo**.

Paso 4



La cuenta Nexxt Solutions Home ha sido configurada satisfactoriamente.


Instalación de la bombilla



Gire la bombilla LED multicolor en sentido horario en el zócalo GU10 hasta que quede asegurada en su lugar.


Agregar dispositivo

Paso 1




Seleccione **Agregar dispositivo** y a continuación, la bombilla inteligente.

Paso 2




Encienda la bombilla inteligente. Debe conectarse a una red **Wi-Fi de 2.4GHz**. Ingrese la contraseña de la red. Asegúrese de utilizar la clave correcta, de lo contrario, no se conectará el dispositivo.

Paso 3




Verifique que el LED del dispositivo parpadea rápidamente. Si la luz no aparece intermitente, reinicie la bombilla. Apague la luz con el interruptor, espere 5 segundos antes de volver a encenderla. Pulse la opción **Confirmar que la luz parpadea rápidamente** para continuar.

Paso 4



Cuando la notificación **Dispositivo incorporado** exitosamente aparezca en la pantalla, asigne una ubicación y seleccione **Terminar**.

Funciones



Bombilla: Enciende y apaga el dispositivo.

Blanco: Cambia la intensidad del brillo y temperatura del color blanco.


Color: Cambia el color, el brillo y la saturación de la bombilla.

Escena: Incluye varias escenas preprogramadas, más cuatro configurables por el usuario.

Horario: Le permite programar la hora y el día cuando desea conectar o desconectar el dispositivo.


Configuración del horario

Paso 1




Haga clic en el ícono del **horario** para abrir la pantalla **Agregar horario**.

Paso 2



Defina el horario que desea programar. Seleccione **Repetir** para configurarlo. Seleccione **Cambiar** para alternar el estatus del horario entre activo e inactivo. Seleccionar **Nota**, **Notificación** para activar o desactivar las notificaciones. Haga clic en **Guardar** en la sección superior derecha de la pantalla para almacenar un horario.


Borrar configuración



Con el fin de eliminar un horario, deslice el ítem a la izquierda en iOS, pero mantenga presionado el **Horario** respectivo de utilizar Android, seguido de **Borrar** al final.

Configuración

Pulse el ícono del lápiz ubicado en el borde superior derecho de la pantalla.



Denominación del dispositivo: cambia el ícono y el nombre del dispositivo, además de permitir la asignación de una nueva ubicación.

Nota: haga clic en el ícono del lápiz para acceder al menú correspondiente a la denominación del dispositivo.

Información del dispositivo: exhibe los datos relacionados con la bombilla.

Activación rápida y automatización: enlaza la bombilla Wi-Fi con otros productos inteligentes para controlarlos en forma automática mediante un comando especial.

Control mediante otras plataformas: habilita el reconocimiento de la voz a través de Alexa y Google Assistant.

Notificación de desconexión: botón selector a través del cual es posible habilitar/inhabilitar esta función.

Compartir dispositivo: permite compartir el acceso a la bombilla Wi-Fi con familiares y amigos.

Crear grupo: facilita la gestión de dispositivos al seleccionar y clasificar múltiples componentes bajo un solo grupo.


Comentarios: comuníquese con nosotros si ha tenido alguna dificultad al instalar el producto.

Agregar pantalla de inicio: incorpora el acceso instantáneo al dispositivo desde la pantalla de su teléfono móvil.

Actualización del firmware: cada cierto tiempo se integran nuevas funciones o actualizaciones mediante versiones mejoradas del microprograma.

Eliminar dispositivo: permite desvincular el dispositivo de la cuenta de Nexxt Home.


Compartir dispositivo



Seleccione **Compartir dispositivos** seguido de **Agregar acceso compartido**. Ingrese el número de teléfono o dirección de correo electrónico de familiares y amigos. Seleccione **Terminar**. El o los usuarios que acaba de configurar desde ahora van a tener acceso a la bombilla inteligente.

Nota: familiares o amigos necesitan establecer su propia cuenta de Nexxt Solutions Home para tener acceso al dispositivo.

Borrar un usuario



Para borrar un usuario en Android, mantenga presionado el nombre que desea eliminar. En iOS, deslice el nombre del usuario hacia la izquierda. Seleccione **Borrar**. Una notificación para confirmar que usted ya no desea compartir el dispositivo con el usuario seleccionado va a aparecer en pantalla. Seleccione **Confirmar**.



FCC ID: X4YHABUC310 / X4YHABUC320

Nexxt Solutions® es marca registrada. Todos los derechos reservados. Amazon, Alexa y todos los logos relacionados son marcas registradas de Amazon.com, Inc. o sus afiliados. Google, Android y Google Play son marcas registradas de Google Inc. Todas las demás marcas y nombres comerciales son propiedad de sus respectivos dueños. Fabricado en China.



Smart **Wi-Fi LED**
color bulb